


per 4 It	einforcement 2> at about 20" lo makes it easie ecure to screw ' plywood toget	ng for each hopp r and more the	er	
ssembled 4 ba	egger system			\bigtriangledown
lagger l	Hopper	Plans		
Plans 3/4" Plywood				
DWG NO	1		REV	
WEIGHT		SHEET 1/3		




1" aluminum square tube is commonly available and a M8 - 40 bolt can be drilled through the aluminum and supported by 2 2x4s screwed into the side scale support pieces of plywood. The top of the 2x4 should be 1" from the top of the side panels so that the 1" square tube can be flush with the top of the side panels.

 \rightarrow


Secure the square tube with wood lag screws into the 2x4 tight to prevent too much scale vibration when filling.


Holes in the 48" long square tube can be drilled at 6" from the ends and 12" in between each for a total of 4 holes for 4 scales.

If you have a smaller quantity of baggers, you can drill the holes for future expansion while it is easy.



agger Hopper Plans							
Bar, support and holes							
		DWG NO		REV			
	WE	IGHT	SHEET 2/3				





 \rightarrow

Mount Baggers using $\frac{7}{8}$ wood screws through holes on the steel trough. Space center of bagger holes at 6" from edge of the plywood and then 12" between them on center

Bottom of the hopper can be made with flat pieces to allow pellets to flow down into auger.

Gaps can be sealed with spray foam, tape or precisely cut wood.

Combo pellets can stay in the hopper between sessions so no need to empty the hoppers between runs.

		PROJECT			
		Fenrir Bagger Hopper Plans			
	APPROVED	SIZE CODE	DWG NO		REV
	CHECKED	В			
	DRAWN Fenrir 2022-05-20	SCALE 1:30 WE	EIGHT	SHEET 3/3	
<u></u>					